

Fitting Instructions for Water-cooled Bonneville T100 & Street Twin TEC Centre Stand Kit

1. Remove right hand silencer (T100 model only)
2. Fit bushes into stand & grease with multipurpose grease



3. Grease the pivot pin and slide through the mounting points on the frame and through stand bushes



4. Locate bush with slipped button head bolt



5. Fit the spring pivot screw to the frame after removing the plastic hole plug
6. Fit the spring to the pivot screw and loop on stand. It will be easier to fit the spring in the fully retracted position
7. Fit the stop rubber to the hole in the left hand silencer
8. On after-market exhausts you may need a stop bracket for the stop rubber. This fits to the inside of the left hand rear foot rest bolt bracket - may have to be bent to fit depending on the type of exhaust.
9. Refit the silencer (T100 only)
10. You may have to reposition the silencer clamp bolt slightly to prevent fouling the stand spring